

General guidelines

- Make sure the tracker is not fully surrounded by metal parts, it blocks the signal.
- Protect the tracker by the container's shape if possible.
 - Between metal ribs
 - On metal studs
- Do not install the tracker on outside sticking parts of the container, transportation might damage the tracker.
- Keep the picking up and putting down of the container in mind. Do not install the tracker close to the pick up parts of the container
- Avoid installation on moving parts of the container at all time.
- Do not install the tracker inside the container

